



DV-EL1000 – Portable Emergency Lighting Case



DV-EL1000 with Lithium-Ion Battery is a self-contained lighting solution for portable lighting. It is the perfect lighting solution for disaster and emergency response, road block and inspection stations, roadside assistance, scene lighting and other portable lighting scenarios.

EL-1000 is a fully portable and rechargeable unit and emits a wide flood of light ideal for the mobile application platform. This is a self-contained and portable light tower package that offers high power and extreme portability in a compact and durable design. The unit is fitted with a basic LED 21W lamp that is constructed of extruded aluminium with polycarbonate lens. There are various LED light options available to cater for different operation requirements.

The EL-1000 will operate up to 9 hours by Lithium-Ion Battery. The LED lamp can be positioned at various angles.

This portable emergency lighting case is designed to be easily deployed and set up. Approximately the size of a carrier suitcase, it has a collapsible handle and elastic wheels for easy transport and handling.

Specifications	
Model Name	DV-EL-1000
Basic Lamp Type	21W LED Work Light
Input	DC 12V – 24V (Car Cigarette Charger) / AC 110 – 220V
Battery Capacity	14.4V / 21V
Battery Type	Rechargeable Lithium-Ion
Run Time	9 hours
Dimension	350 x 570 x 260mm (Cabinet) / 350 x 2100 x 260mm (Set Up)
Weigh	16.6kg (excluding lamp)
Output Voltage	12V (Lamp) / 5V (Mobile Device)

*Specifications are subject to change without prior notice.

Golden Season Pte Ltd