



Military Charger - GS8001 - MKII single bay charger



The GS8001 MKII single bay charger is designed to quickly and efficiently charge / recharge BB-2590/U batteries and compatible models. The charger is fitted with a durable aluminum casing, LED status indicator and is protected against reverse polarity charging and short circuits. The GS8001 MKII is an intelligent charger which varies the charging stages for optimal charging and reconditioning of BB2590/U batteries.

Specifications	
DC input	19v - 30v
AC input	220-240VAC
Charging rate	5.0A
Battery type	Li-Ion
LED indicator	*No light - No battery detected *LED1 - Red light - Power detected *LED2 - Green light - On *LED2 - Red light - Charging *LED2 - Green light - Charge complete
Connectors	2.5mm centre positive
Color	Silver
Casing material	Aluminium
Dimensions	160mm x 90mm x 52mm
Operating temperature	0° - 45°C
Storage temperature	-25°C - 70°C

*Specifications are subject to change without prior notice.

Golden Season Pte Ltd